







# Astrobeat 240/360

## WATER-COOLING

产品使用说明

版本号: L003

<b>1</b>  散热器主体	<b>2</b>  Intel安装扣具	<b>3</b>  AMD安装扣具
<b>4</b>  安装螺母	<b>5</b>  硅脂刷	<b>6</b>  导热硅脂
<b>7</b>  安装底板	<b>8</b>  Intel 17XX 底板支撑柱	<b>9</b>  AMD安装螺杆
<b>10</b>  机箱螺丝	<b>11</b>  Intel 115X / 1200 底板支撑柱	



# Astrobeat 240/360

## WATER-COOLING

Product Instructions

Version number: 1003

<b>1</b>  Radiator	<b>2</b>  Intel installation buckle	<b>3</b>  AMD installation buckle
<b>4</b>  Installing nuts	<b>5</b>  Silicone grease brush	<b>6</b>  THERMAL GREASE
<b>7</b>  Installing the base plate	<b>8</b>  Intel 17XX base plate support column	<b>9</b>  AMD installation screw
<b>10</b>  Chassis screws	<b>11</b>  Intel 115X/1200 Backboard Support Column	

