

The Fountain of Youth

Electric Heated Towel Warmer




Model shown: S3-M-CHR-N



Product Specification

This drawing is for design reference only. For specific drilling/hole positions, please refer to the actual product.	Products and specifications are subject to change without notice. Please contact customer service for Full Size Product Template.	Finish/Color
		Please refer to the PRICE CATALOG for all finishes/colors/control options.



S3-M


Tolerance on dimensions: $\pm 0.3'' / \pm 8\text{mm}$

MODEL	A	B	C
S3-M	21.6" 550mm	39.4" 1000mm	11.8" 300mm

Model	S3-M
Package dimensions /in/mm	42.52x24.65x14.57 in*/1080x626x370mm
Power/W	74
Gross weight /lb/kg	57.43lb/26.05kg
Net weight /kg	22.05lb/10kg

Mounting & Hole Layout

This drawing is for design reference only. For specific drilling/hole positions, please refer to the actual product.	Products and specifications are subject to change without notice. Please contact customer service for Full Size Product Template.	Finish/Color
		Please refer to the PRICE CATALOG for all finishes/colors/control options.



Stud Wall Installation

NOTE The Rough Body Fixed Black Box Must Be Installed Flush With the Exterior Edge Of The Wood Studs/Cross Beams To Ensure Proper Rough-In Dimension.



NOTE The thickness of the finished wall application (including drywall, and tile, stone, etc..) should not be less than 0.5in/15mm and should not exceed 1.5in/40mm.

Tolerance on dimensions: ±0.3"/±8mm

MODEL	D	E	F	G	H	I	J	A1	B1	C1	D1
S3-M	9.5" 242mm	1.1" 28mm	25.9" 657mm	2.6" 67mm	12.1" 307mm	0.7" 17mm	51.2" 1300mm	5.7" 145mm	4.1" 103mm	2.3" 58mm	1.4" 35mm

Electrical Diagram

For Integrated Control





Push Button-N

There is a push button on the bottom that can be used to turn the product on or off.

Electrical Diagram

For Optional -XA Digital Metal Knob Control




Push Button-N

There is a push button on the bottom that can be used to turn the product on or off.

Electrical Diagram

For Optional -XM Digital Metal Knob Control



Push Button-N

There is a push button on the bottom that can be used to turn the product on or off.