

Specification for 16 anti-drone trolley case

User manual



Thank you for using this anti-drone device.

In order for you to operate the equipment skillfully as soon as possible, we are equipped with a detailed user manual,

From which you can get about the product introduction, use methods, system Settings! And safety precautions and other aspects of knowledge.

We are very careful and rigorous in the preparation of this manual, and believe that the information provided in the manual is correct and

reliable, but there will inevitably be mistakes and omissions, please

kindly bear with us and warmly welcome your correction. Disclaimer:

Before you use this product, please read the product related operating instructions and this statement carefully to ensure that

The product is used correctly. Use this product if you do not follow or do not follow the instructions and precautions in this document

There will be risks of product damage. Some contents of this document may change as the product hardware is upgraded

Contents are subject to change without prior notice.

By starting to use this product, the user shall be deemed to have approved and accepted all contents of this Statement. This product is strictly prohibited

Disassemble without permission.

Packing list:

1. Product host *1

2. Power cable *1

3. Omnidirectional fiberglass antenna *16

4. Remote control *1. Product features

1, the use of rod design, fixed installation.

2, the switching power supply external heat dissipation is better, longer working time.

3, custom antenna, good anti-interference performance.

4. Integrated host antenna.

5, each group of host 12 IP67 cooling fan design

6, single switch technology, control power output.

7, power supply AC220V or DC24-28V, can be customized.

8, waterproof grade IP65

9. 3000W power supply to ensure normal power output

II.Detailed explanation of product pictures



Pull rod box counterbody



Remote control box *1



Power cable *2

Interference frequency	频段： 400M 400-470mhz50W 800M 700-850mhz50W 1.0G 850-1000MHZ50W 1.1G 1000-1150MHz50W 1.2G 1150-1300MHZ50W 1.4G 1300-1450MHz50W 1.5G 1550-1650mhz50w 1.8G 1805-1920mhz50w 2.1G 2010-2170MHZ50w 2.3G 2320-2485MHZ50w 2.4G 2400-2500mhz50w 2.5G 2320-2675MHZ50w 3.4G 3330-3600MHz50w 4.5G 4750-4960mhz50w 5.2G 5150-5350mhz50w 5.9G 5700-5960mhz50w	Feature	Cut off map transmission, eviction, forced landing
Product size	62*42*39	Product weight	50kg
Directed countermeasure	1500-2500m (Depends on the model and altitude of the drone)	base	Tie rod or fixed mounting
Power supply mode	220v transform 24V; 12V transform 220V reconversion 24V (be customized)	Overall power	800W
Jamming mode	Constant frequency electromagnetic wave	Place of use	Army, National defense, military, armed police,

			transportation, large venues air defense, etc
Packing method	Flight case	Package size	84*57*51cm

Frequency band description:

Drone crash landing; Open 1.5G, 2.4G, 5.8G;

Get rid of drones; Open 2.4G and 5.8GB.

Forced landing of drones; Open 900mhz, 1.5G, 2.4G, and 5.8G

400mhz is the remote control band of domestic drones, as well as our common TV remote control and car

Keys, children's toys, etc.

900mhz is a commonly used remote control band for industrial drones, custom drones and large drones

The commonly used remote control frequency band.

1.2G is China's self-developed Beidou navigation system, which will also be used in the UAV industry in the future.

As the second positioning system of 1.5G (GPS), it will be used in the future.

Iv. Application scenarios

Forbid "black fly" to be the guardian of low altitude security

With the rapid increase in the number of civilian drones, the number of

various "black flight" incidents has also increased rapidly

Liters. The company's products are mainly used in airports, high-speed rail stations, military bases, major government conferences, Prison management, petrochemical industry, border defense, breeding bases and cultural and sports activities.



Airport



Rail station



Military base



Major conference




Prison



Petrochemical industry



Frontier defence



Breeding base



Activities

Matters needing attention

1. The equipment should be installed in a high space without shelter, and avoid high-voltage lines and electromagnetic wave interference as far as possible
2. Connect the antenna according to the corresponding frequency band before the device is used, and then power on the device
3. The warranty period is 12 months, which guarantees the operability of the product and promises to carry out warranty maintenance in case of

failure during the warranty period, provided that the consumer complies with the conditions of operation, transportation and storage.

3. We reserve the right to make changes to the product design in order to improve its technical characteristics and reliability.

This product is suitable for places where drones are prohibited to fly!