

Thermo-hygrometer user manual

KD-70

Product specifications

Temperature measurement range: $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$ ($-4^{\circ}\text{F} \sim +140^{\circ}\text{F}$)

Temperature measurement accuracy: $\pm 1^{\circ}\text{C}$ (1.8°F)


Temperature resolution: 0.1

Humidity measurement range: 20%RH-99%RH

Humidity measurement accuracy: $\pm 5\%\text{RH}$

Humidity resolution: 1%

Power supply: CR2032




Basic functions

Temperature display / Humidity display

$^{\circ}\text{C}/^{\circ}\text{F}$ temperature switch display

Comfort indicator

Operation method



Hang hole for lanyard

Button inside the back cover, long press the button for 1.5 seconds to power on/ power off, Double click to select the temperature unit: $^{\circ}\text{C} / ^{\circ}\text{F}$

The bracket is stored in the back shell, open the back cover, remove and attach to the hole, the hygrometer can stand on the table.

Comfort Indicator



Comfortable



Normal



Uncomfortable

Humidity \ Temperature	Humidity		
	< 40%	40%-74%	> 74%
< 22°C			
22°C-28°C			
> 28°C			