

Instruction Manual

Features:

1. Function: Temperature measurement, humidity, calendar, alarm clock and weather forecast function.
2. Temperature range: -10 ~ 60°C (14°F ~ 140°F), temperature measurement period of 2 seconds, accuracy: $\pm 1^{\circ}\text{C}$, resolution: 0.1°C (if the current testing date exceeds this range, it will show HH or LL)
3. Humidity range: 10%-99%, humidity measurement accuracy: $\pm 5\%$, resolution: 1%
4. USB charging function supported (Battery capacity 200mah)
5. Backlight function (optional)

Key Function:

- Click (|||) key to switch between Time and Alarm
- Hold (|||) key for 2 seconds to Time setting mode
- Click (✓) key for 2 seconds to select the temperature unit: °C or °F
- Click (∧) key to check MAX/MIN Temperature & Humidity, in this interface, press (∧) key for 2 seconds to delete memory
- Click any key to start back light and last for 10 seconds without any operation
- Click (✓) (∧) (|||) 3 buttons at the same time to power off

Time Setting mode:

- Hold (|||) key for 2 seconds to Time setting mode, Click (∧) (✓) key to select 12/24HR
- Click (|||) key to next step, Click (∧) to add the date and hold the key to speed up setting, Click (✓) to reduce the date and hold the key to speed up setting
- After setting, Click (|||) to confirm and quit
- The Sequence is "12/24HR" - "Time" - "Date" - "Quit"
- In setting mode, without any operation about 10 seconds will return back to time mode automatically

Alarm Setting mode:

- In time mode, Click (|||) key to switch to Alarm mode, Click (∧) to turn on/off alarm
- In alarm mode, Click (∨) key to choose the alarm pattern 5/6/7 (5 means alarm on Monday to Friday, 6/7 means Monday to Saturday and Sunday)
- Hold (|||) key for 2 seconds to Alarm setting mode
- Click (∧) to add the time and hold the key to speed up setting
- Click (∨) to reduce the time and hold the key to speed up setting
- The Sequence is "Hour" - "Minute" - "Quit"