


Thermo-hygrometer user manual

Features

- LCD display
- Insert design
- Simple appearance
- Ultra-long life battery



Technical parameter

- Temperature range: $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$ ($-4^{\circ}\text{F} \sim 140^{\circ}\text{F}$)
- Humidity range: 20% ~ 99%RH
- Accuracy: $\pm 1^{\circ}\text{C}$ / $\pm 5\%\text{RH}$
- Resolution: 0.1°C / 1%RH
- Power: 1.5V button battery LR44 *2


Instruction

- Open the battery cover to put in two LR44 battery correctly, pay attention to the polarity
- Display when put in the batteries. Pls take out the batteries when not use for long time
- LCD display HHH when temperature is higher than 70°C
LCD display LLL when temperature is lower than -50°C
- Insert size: 45.5*26mm(For reference only, please adjust according to the actual situation)

Operation method

Multifunction button

Long press the key 1.5 seconds to power ON / OFF
Double click to switch $^{\circ}\text{C}$ / $^{\circ}\text{F}$



Battery cover

Slide down to open the cover and replace battery