

Thermo-hygrometer user manual

Product specifications

Temperature measurement range: -20°C ~+60°C (-4°F~+140°F)

Temperature measurement accuracy: $\pm 1^{\circ}\text{C}$ (1.8°F)

Temperature resolution: 0.1

Humidity measurement range: 20%RH-99%RH

Humidity measurement accuracy: $\pm 5\%\text{RH}$


Humidity resolution: 1%

Power supply: CR2032

Basic functions

- 1.Mounting mode:Double side tape / Holder
- 2.Temperature display
- 3.Humidity display
- 4.Comfort indicator
- 5.°C/°F switch

Operation method



- 1.Press and hold the key for 1.5 seconds to turn on;
- 2.Double click the key to switch the temperature unit to °C/°F;
- 3.Press and hold the key for 1.5 seconds to power off;

Wall sticker

Holder