

Thermo-hygrometer user manual

Features

- LCD display
- Insert design
- Simple appearance
- Ultra-long life battery



Technical parameter

- Temperature range: $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$ ($-4^{\circ}\text{F} \sim 140^{\circ}\text{F}$)
- Humidity range: 20% ~ 99%RH
- Accuracy: $\pm 1^{\circ}\text{C}$ / $\pm 5\%\text{RH}$
- Resolution: 0.1°C / 1%RH
- Power: 1.5V button battery LR44 *2


Instruction

- Open the battery cover to put in two LR44 battery correctly, pay attention to the polarity
- Display when put in the batteries. Pls take out the batteries when not use for long time
- LCD display HHH when temperature is higher than 70°C
LCD display LLL when temperature is lower than -50°C
- Insert size: 45.5*26mm(For reference only, please adjust according to the actual situation)

Operation method

Multifunction button

Long press the key 1.5 seconds to power ON / OFF
Double click to switch $^{\circ}\text{C}$ / $^{\circ}\text{F}$



Battery cover

Slide down to open the cover and replace battery

温湿度计说明书

产品简介

- LCD 屏幕显示
- 嵌入式设计
- 简洁外观
- 超长续航



技术参数

- 温度范围: $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$ ($-4^{\circ}\text{F} \sim 140^{\circ}\text{F}$)
- 湿度范围: $20\% \sim 99\%\text{RH}$
- 精度: 温度 $\pm 1^{\circ}\text{C}$ 湿度 $\pm 5\%\text{RH}$
- 电池: 1.5V纽扣电池 LR44 *2


使用说明

- 使用安装两颗LR44纽扣电池, 请注意电池正负极方向
- 长时间不使用时, 请将电池取出
- 温度高于 70°C 时LCD显示HHH, 温度低于 -50°C 时LCD显示LLL
- 嵌入尺寸: $45.5 \times 26\text{mm}$ (仅供参考, 请根据实际使用调整)

操作方法

多功能按键

长按1.5秒 开关机, 双击可切换温度单位 $^{\circ}\text{C}/^{\circ}\text{F}$



电池仓

向箭头方向滑动打开电池仓, 可更换电池