## **Barcode Scanner**

## Manual Guide

## Table of contents

Working Mode	1
Upload mode	
Power and Standby Setup	3
Language Setup	3
Capital & Lowercase Setup	4
Trigger Mode	4
Buzzer Setup	4
End Mark	4
Reverse Code Reading(black background)	4
UPCA	4
UPCE	5
EAN8	5
EAN13	6
ISBN	6
ISSN	6
CODE 39	6
CODE 32	7
CODE 128	7
CODE 93	7
CODE 11	8
CODABAR	8
Industrial 2 of 5	8
Interleaved 2 of 5	8
MSI	8
GS1 Omnidirectional	9
GS1 Limited	9
Febran	9
Add Prefix/Suffix	9
Hide characters	9
Rarcode Table	10

■If the scanner does not work or buzzer rang "Di-Di-Di-Di-Di-", please stop using the scanner and charging it immediately.



Decoding Restore Defaults



Wireless Restore Defaults

Note: Scan "Decoding Restore Defaults" and "Wireless Restore Defaults" in order to restore the scanner to the factory status.

## Working Mode

### ■2.4G Match Operation:

2.4G receiver has been matched by default, plug in the receiver and scan the "2.4G Mode" setting code to use. If you need to match it again, first unplug the receiver, then re-plug the receiver into the computer, scan the "2.4G Mode" setting code within 20 seconds, the match is successful.



### **■Bluetooth Match Operation:**

Scan the "Bluetooth HID Mode" setting code, the blue indicator flashes quickly, turn on the device's Bluetooth option, click "Scanner xxx", the blue indicator becomes steady on, the match is successful.



Bluetooth HID Mode (Only to Bluetooth products)

### ■Bluetooth BLE Mode:

Scan the "Bluetooth BLE Mode" setting code. (Developers use, general users scan carefully)



Bluetooth BLE Mode (Only to Bluetooth products)

To show and hide iOS keyboard (Only to Bluetooth products)



iOS keyboard Show/Hide



Double click show/hide iOS keyboard--ON/OFF

## Upload mode

►Instant upload mode :Instant upload data to your computer



Instant Upload Mode (1)Upload successfully: the buzzer rang"Di".

(2)Upload failed: the buzzer rang"Di-di-di".

► Storage Mode :In storage mode, the barcode will be stored in scanner's own memory and will not come up on your computer instantly. The barcode comes up on your computer only when you scan the settings code "upload data" within the wireless transmission range.



Storage Mode

Note: During use, if data cannot be uploaded, please confirm whether it is set to storage mode.

▶ Non-losing Mode :The barcode will be uploaded to the receiver in real-time when the scanner is in wireless transmission range. When the scanner is out of the wireless transmission range, the data will be stored in scanner's own memory . After scanner is reaching the wireless transmission range,scan "Upload Data" setting barcode,the lost data which are stored will be uploaded to the computer automatically.



Non-losing Mode

Note: Before using the non-losing mode, it is better to scan the code "Clear Data" to clear the data of scanner.

High Upload Speed(*default)	Low Upload Speed
Show Total Storage	Upload Data
Cicai Dala lo cicai lile dala di si	allici.



Clear Data

Power and Standby Setup		
Battery Reserve	Standby Immediately	
Set the time for automatic	2 Minutes-Default	
10 Minutes	20 Minutes	
8 hours	Never Standby	
► Set the time for automatic shutdo For example, if you want to set the p scan "Set the time for automatic shutdo		
Languaç	ge Setup	
UNITED STATES*		
FRANCE	GERMANY	
SPAIN	SPAIN(MEXCIO)	
ITALY	PORTUGAL(BRAZIL)	
TURKEY	PORTUGAL	
CZECH REPUBLIC	NORWAY	

FINLAND(SWEDEN)

Capital & Low	ercase Setup		
Swap Capital/Lowercase	No Swap*		
All Capital	All Lowercase		
Trigge	r Mode		
Continuous Mode	Auto-sense(optional)		
Buzzei	r Setup		
Volume-ON*	Volume-OFF		
End Mark			
CR	None		
TAB	LF+CR		
Reverse Code Reading(black background)			
White in black background-ON	White in black background-OFF*		
UPCA			
UPCA-ON	UPCA-OFF		

UPCA Check Digit-ON	UPCA Check Digit-OFF
UPCA System Digit-ON	UPCA System Digit-OFF
	UPCA to EAN13 -OFF
UPCA to EAN13 -ON	PCE
UPCE-ON	UPCE-OFF
UPCE Check Digit-ON	UPCE Check Digit-OFF
UPCE System Digit-ON	UPCE System Digit-OFF
UPCE to UPCA-OFF	UPCE to UPCA-ON
EA	N8
EAN8-ON	EAN8-OFF
EAN8 Check Digit-ON	EAN8 Check Digit-OFF
EAN8 System Digit-ON	EAN8 System Digit-OFF

# EAN13 EAN13 Check Digit-ON\* EAN13 Check Digit-OFF **ISBN** EAN13 to ISBN-OFF FAN13 to ISBN-ON\* ISSN EAN13 to ISSN-ON\* FAN13 to ISSN-OFF UPC/EAN Extra Code Extra Code-OFF CODE 39 Transmit Check Character Do Not Transmit Check

Verification

Character Verification

CODE39 MOD43-OFF	CODE39 MOD43-ON
Output Start&End Digit-ON	Output Start&End Digit-OFF
Full ASCII-OFF	Full ASCII-ON
	DE 32
CODE32-ON	CODE32-OFF*
COD	E 128
CODE128-ON*	CODE 128-OFF
CODE 139 Charle Digit ON	CODE128 Check Digit-OFF*
CODE128 Check Digit-ON	DE 93
CODE93-ON*	CODE93-OFF
Transmit Check Character After Verification	Do Not Transmit Check
CODE93 MOD47-OFF	CODE93 MOD47-ON

## CODF 11 One Check Bit-ON Two Check Bit-ON CODABAR Output Start&End Digit-On Output Start&End Digit-OFF Industrial 2 of 5 Industrial 2 of 5-ON\* Industrial 2 of 5-OFF Interleaved 2 of 5 Interleaved 2 of 5-ON Interleaved 2 of 5 terleaved Check 2 of 5-ON Interleaved Check 2 of 5 Transmit Check Character After Do Not Transmit Check Verification Character After Verification MSI

## **GS1** Omnidirectional





GS1 Omnidirectional-ON

GS1 Omnidirectional-OFF

## **GS1** Limited





GS1 Limited-OF

## Febran





Febran-ON

Febran-OFF\*

## Add Prefix/Suffix





Add Prefix

Add Suffix





Save settings

E.g. If you want to add X and Y before the barcode, Please scan the following code in order:

"Add Prefix "→Barcode Table"X"→Barcode Table"Y"→"Save settings"

## Hide characters





Hide the front characters

Hide the behind characters

E.g. If you want to hide the first two characters of the barcode , Please scan the following code in order:

"Hide the front characters"→Barcode Table"0"→Barcode Table"2"

Barcode Table		
SOH	STX	ETX
EOT	ENQ	ACK
BEL	Backspace	TAB
LF	VT	
CR	SO	SI
DLE	DC1	DC2
DC3	DC4	NAK
SYN	ETB	CAN
EM	SUB	ESC
FS	GS	RS
US	SPACE	
		<b>     </b>

%	<b>        </b>	
	2	
4	2 	
7		9
	8	
	>	?
@	A A	B B
C	D	
F	G	
		K

	P	Q
R	S	
R		
X		Z
a	b	
d	e	
g	h	
	k	
m p	n q	o R R

s	l I II	u
	w Z	
Delete	F1	F2
F3	<b>F</b> 4	F5
F6	<b>F7</b>	F8
F9	F10	F11
F12	INSERT	HOME
Page up	Delete	END
Page down	Right arrow	Left arrow
Down arrow	Up arrow	