

Barcode Scanner

Manual Guide

General Settings



Factory Default



Add CR suffix



Clear CR suffix



Add CR suffix and LF suffix



Clear CR suffix and LF suffix

Buzzer Setup



High volume -Default



Medium volume



Low volume



Volume Off

Language	
 American Keyboard	 Germany
 France	 Sweden
 CZECH	 Finland
 Russia	 SWITZERLAND_FRENCH
 ARAB	 Norway
 HUNGARY	 Denmark
 Spain	 Italy

Barcode Type ON/OFF

 All BARCODE TYPES(ON)*	 All BARCODE TYPES(OFF)
 1D CODE(ON)*	 1D CODE(OFF)
 2D CODE(ON)*	 2D CODE(OFF)
 Default all UPC-A settings	
 UPC-A(ON)*	 UPC-A(OFF)
 UPC-A Check Bit (ON)*	 UPC-A Check Bit(OFF)



Default all UPC-A settings



UPC-E0(ON)*



UPC-E0(OFF)



UPC-E Check Bit(ON)*



UPC-E Check Bit(OFF)



UPC-E1(ON)*



UPC-E1(OFF)



UPC-E to UPC-A(ON)



UPC-E to UPC-A(OFF)*



UPC-A to EAN-13(ON)



UPC-A to EAN-13(OFF)*



Default all EAN/JAN-8 settings



EAN/JAN-8(ON)*



EAN/JAN-8(OFF)



Default all EAN13/JAN-13 settings



EAN-13/JAN-13(ON)*



EAN-13/JAN-13(OFF)



ISBN(ON)



ISBN(OFF)*



Default all CODE 128 settings

 CODE 128(ON)*	 CODE 128(OFF)
 Default all GS1-128 settings	
 GS1-128(ON)*	 GS1-128(OFF)
 ISBT-128(ON)	 ISBT-128(OFF)*
 Default all GS1 DataBar Omnidirectional settings	
 GS1 DataBar Omnidirectional(ON)*	 GS1DataBar Omnidirectional(OFF)



Default all Interleaved 2 of 5 settings



Interleaved 2 of 5(ON)*



Interleaved 2 of 5(OFF)



Default all Matrix 2 of 5 settings



Matrix 2 of 5(ON)



Matrix 2 of 5(OFF)*



Default all CODE 39 settings



CODE 39(ON)*



CODE 39(OFF)



Code39 Check Bit(ON)*



Code39 Check Bit(OFF)



Code 39Full ASCII(ON)



Code39Full ASCII(OFF)*



CODE 32 PAF (ON)



CODE 32 PAF(OFF)*



Default all CODE 93 settings



CODE 93(ON)*



CODE 93(OFF)



Default all CODE 11 settings



CODE 11(ON)



CODE 11(OFF)*



Default all CADABAR settings



CODABAR(ON)*



CODABAR(OFF)



Default all NEC 2 of 5 settings



NEC 2 of 5(ON)*



NEC 2 of 5(OFF)



Default all Straight 2 of 5 Industrial settings



Straight 2 of 5 Industrial(ON)



Straight 2 of 5 Industrial(OFF)*



Default all Straight 2 of 5 IATA settings



Straight 2 of 5 IATA(ON)



Straight 2 of 5 IATA(OFF)*



Default all MSI settings



MSI(ON)



MSI(OFF)*



Default all QR CODE settings



QR CODE(ON)*



QR CODE(OFF)



Default all Matrix settings



Data Matrix(ON)*



Data Matrix(OFF)



Default all PDF417 settings



PDF417(ON)*



PDF417(OFF)



Default all Aztec code settings



Aztec code(ON)*



Aztec code(OFF)



Default all China Post (Hong Kong 2 of 5) settings



China Post (Hong Kong 2 of 5)(ON)



China Post(Hong Kong 2 of
5)(OFF)*



Default all Korea Post settings



Korea Post(ON)



Korea Post(OFF)*



Default all Han Xin code settings



Han Xin code(ON)



Han Xin code(OFF)*



Default all Maxi code settings



Maxi code(ON)



Maxi code(OFF)*



Default all Gs1 Composite Code settings



Gs1 Composite Code(ON)



Gs1 Composite Code(OFF)*



Default all Micro PDF settings

 Micro PDF(ON)*	 Micro PDF(OFF)
 Default all Codablock A settings	
 Codablock A(ON)	 Codablock A(OFF)*
 Default all Codablock F settings	
 Codablock F(ON)	 Codablock F(OFF)*
 White in black background-ON	 White in black background-OFF*