

Barcode Scanner

User Manual

Factory Defaults



If the scanner can not work normally, Pls scan "Factory Default"

CR



CR + LF



TAB



USB Keyboard



USB COM



9600bps



115200bps



Enable 1D CODES



Disable 1D CODES



Enable 2D CODES



Disable 2D CODES



High volume



Medium volume



Low volume



Volume Off



US



SPAIN



RUSSIA-cp1251



Vietnam



Russia-koi8-r



FRANCE

