

Manual for S800-24G

All gigabit ethernet switch

01 Product introduction

Product overview

hasivo independently developed S800-24G all gigabit ethernet switch with simple and convenient installation and maintenance means and rich business characteristics, which helps users to create security high performance network. The product can be widely used in the field of data exchange such as home network, multimedia classroom, security monitoring, wireless network and so on.

Port performance

- ◆ Provide 24*10/100/1000M RJ45 ports which can realize line speed forwarding.
- ◆ Each port supports MDI/MDIX automatic flip and duplex / rate self negotiation.
- ◆ Support IEEE 802.3x full duplex flow control and backpressure half duplex flow control.

02 Spare parts list



Network Switch




AC power cable



User manual+Warranty Card

03 Product display

Front



Function switch

Downlink Port

Uplink Port

Indicator

Back



AC Power

Ground screw

Indicator definition:

Indicator	Status	Description
Power indicator: PWR	Green light is always on	Power on normal
	Always off	No power
LINK/ACT indicator: 1~24 [2 and 3 Line]	Light is on	The corresponding port works at 10/100M speed
	Light is flashing	The corresponding port has data transmission
	Always off	The corresponding port hasn't data transmission
1000M indicator: 1~24 [1 and 4 Line]	Light is on	The corresponding port works at 1000M speed

Function:

Function identifier	Work mode	Description
N	Standard switching mode	All ports communicate freely, suitable for common data transmission environment
V	Port isolation mode	The downlink ports are isolated from each other, which is suitable for the use scenarios of connecting wireless AP, suppressing network storm and improving network performance
C	Flow control mode	Port flow balance control, prevent big data flow packet loss, ensure the efficient and stable operation of user network


04 Installation&Points of attention

Checking before installation


- 1.Check whether the accessories are complete. If there is any omission, please contact us.
- 2.Check whether the power supply voltage is consistent with the working voltage of the switch,so as to avoid the equipment burning out due to high voltage.
- 3.Ensure that the installation position of the switch has certain ventilation and heat dissipation conditions.
- 4.Please keep the power off during installation to avoid potential safety hazards.
- 5.Please install the switch on a stable plane to avoid falling and damage.

Install to desktop

- 1. Place the switch on the horizontal desktop in the ventilation area.




- 2.Insert the data cable



As shown in the figure, insert the crystal head of the data cable into the network port. When you hear a clear click, it indicates that the crystal head is successfully connected with the network port of the switch. Just plug in all the network cables of the network equipment in this way.

- 3.Connected the power




AC Power in 100V~240V
50/60Hz

Points of attention

1. Do not stack heavy objects on the switch to avoid danger.
2. In order to avoid the risk of electric shock, please do not open the machine box when the switch is working, even if it is not powered on, please contact us in case of any problem.
3. Before cleaning the switch, pull out the power plug of the switch. Do not wipe it with wet fabric or clean it with liquid.
4. If the power adapter is damaged, do not replace it with other power adapters. This switch should be equipped with original power adapter.

05 Application



06 Common troubleshooting

- ⚠ The PWR indicator is not on after the power is connected → Check whether the power adapter and plug are connected correctly, whether the power cord is damaged, and whether the power adapter is damaged.
 - ⚠ Switch cannot communicate after power up → Check whether the switch indicator is on. If the indicator is off, the network cable is not connected. If the indicator is on, the communication fault is indicated.
 - ⚠ Switch network speed suddenly become very slow → Take off the plug and restart the switch.
- [If the above problems or other switch problems can not be solved, please contact us for technical support]

07 Product parameter

Model	S800-24G
Product	All Gigabit 24 Ports Ethernet Switch
Fixed Port	24*10/100/1000M Base-TX RJ45 (Data)
Network Protocol	IEEE 802.3 IEEE 802.3i 10BASE-T IEEE 802.3u 100BASE-TX IEEE 802.3ab 1000BASE-T IEEE 802.3x IEEE 802.1q
Function	N_Standard normal; V_Port isolation; C_Flow Control mode
Port Specification	10/100/1000BaseT (X) Auto
Transmission Mode	Store and Forward (full wirespeed)
Bandwidth	56Gbps
Packet Forwarding	40.32Mpps
MAC Address	8K
Buffer	4.1M
Transmission Distance	10BASE-T : Cat3,4,5 UTP(≤250 meter) 100BASE-TX : Cat5 or later UTP(150 meter) 1000BASE-TX : Cat6 or later UTP(150 meter)
Watt	≤20W
LED Indicator	PWR:Power LED 1-24:(Link LED=10/100M、1000M=Gigabit Link)
Power	Built-in Power AC:100~240V 50-60Hz 1A
Operating Temperature/Humidity	-10~+55°C;5%~90% RH Non coagulation
Storage Temperature/Humidity	-40~+75°C;5%~95% RH Non coagulation
Product size/Packing size (L*W*H)	305mm*140mm*45mm 410mm*275mm*95mm
N.W/G.W (kg)	1.2kg/2.1kg
Installation	Desktop
Lightning protection level	3KV 8/20us; IP30
Certificate	CE mark, commercial;CE/LVD EN60950; FCC Part 15 Class B;RoHS;
Warranty	Whole device for 1 year(Accessories not included)

PS: We will try our best to check the errors in the printing and pictures, but hasivo will not be responsible for any possible omissions. The appearance, specifications, parameters, prices and supply conditions of the products listed on this page are subject to change without notice.



Sichuan hasivo electronics CO.,LTD.

Address: NO.9 Anping street, New District, Economic Development Zone, Meishan City,Sichuan Province,China.

Post code: 620010

Offical website: <http://www.hasivo.com>

©2013-2022 Sichuan hasivo electronics CO.,LTD. All rights reserved

After-sale service: 028-38288776

Technical service: 028-38119776