


Firstly, change the picture format to be **BMP**, (max size : **384\*600**)

And add the LOGO by “ IPrinter.exe”

The screenshot shows the "printer" window with various settings. The "Select Comm Port:" dropdown is set to "USB001" and is circled in red. The "Select Baud Rate:" dropdown is set to "9600". The "IP Address:" field is set to "192 . 168 . 1 . 101". The "NV Logo Demo:" section has a button labeled "NV Logo Download" which is also circled in red. The "Default Code Page:" dropdown is set to "PC437(Std.Europe)(1)". The "Pos58 Serial Port Settings:" dropdown is set to "19200". The "Pos80 Repeat Printing:" section has radio buttons for "Enable" (selected) and "Disable". The "Com Port Status Report:" section has a button labeled "Check Status". At the bottom, there are four buttons: "Print Test", "Open Cash Box", "Cut Paper", and "Cancel". The status bar at the bottom shows the date "2014-04-22" and the time "09:13:55".

