


Firstly, change the picture format to be **BMP**, (max size : **384*600**)

And add the LOGO by “ IPrinter.exe”

The screenshot shows the 'printer' window of the IPrinter.exe application. The window has a blue title bar with the text 'printer'. The main area is grey and contains several settings sections. The 'Select Comm Port:' section has a dropdown menu showing 'USB001', which is circled in red. The 'Select Baud Rate:' section has a dropdown menu showing '9600'. The 'IP Address:' section has a text box showing '192 . 168 . 1 . 101'. The 'NV Logo Demo:' section has a button labeled 'NV Logo Download', which is also circled in red. The 'Default Code Page:' section has a dropdown menu showing 'PC437(Std.Europe)(1)' and a button labeled 'Set Default Page'. The 'Pos58 Serial Port Settings:' section has a dropdown menu showing '19200' and a button labeled 'Set Baud Rate'. The 'Pos80 Repeat Printing:' section has two radio buttons, 'Enable' (selected) and 'Disable', and a button labeled 'Set Repeat Mode'. The 'Com Port Status Report:' section has a button labeled 'Check Status'. At the bottom, there are four buttons: 'Print Test', 'Open Cash Box', 'Cut Paper', and 'Cancel'. The status bar at the very bottom shows the date '2014-04-22' and the time '09:13:55'.

